


### Checking Compressor Oil

The oil cannot be checked where the manifold lines attach to the compressor. In order to properly check the oil for V-5 and Sanden type compressors you must remove the oil fill bolt located on the compressor housing. This bolt is shown here on the two different types of compressors mentioned.



The proper oil amount is also printed on the compressor label as shown here. Please note that attempting to check the oil level from the manifold connection will not result in a correct measurement. The only way to properly check the oil is to drain the compressor completely through the oil fill bolt shown above.